

FUEL FILTER [SKYACTIV-D 1.5]


id0114q2707000

Purpose, Function

- The fuel filter removes foreign matter and dirt in the fuel.


Construction

- The fuel filter is installed between the fuel tank and the supply pump and it is located next to fuel tank.



am2zzn00003282

- The fuel filter consists of the fuel warmer and the cartridge.



am2zzn00003283